

Fig. 2




Fig. 3

300

The screenshot displays the 'HP LaserJet Copier' dialog box. It is divided into two main sections for configuring two separate copy jobs. The top section is for a job to 'HP 2000C Printer' and the bottom section is for a job to 'HP LaserJet 8150mfp'. Both sections include options for the number of copies, collation, output range, copy quality, and various finishing options like collate, staple, bind, photo, fold, stitch, trim, edge, and paginate. The 'Start Copy' button is at the bottom.

Job 1 Configuration (Top):

- Copies:** Number of Copies: 1, Collation: ☒ Collation
- Reduce/Enlarge:** ☒ Standard Sizes, Original (100%)
- Copy Quality:** ☒ Photo
- Printer:** HP 2000C Printer
- Options:** ☒ I want to copy to another printer...

Job 2 Configuration (Bottom):

- Copies:** Number of Copies: 1, Collation: ☒ Collation
- Reduce/Enlarge:** ☒ Standard Sizes, Original (100%)
- Copy Quality:** ☒ Photo
- Printer:** HP LaserJet 8150mfp
- Options:** ☒ I want to copy to another printer...

Buttons: Start Copy, Cancel, Help, Save as Default

302

304

306

310

312

318

320

322

326

328

308

316

314

324

330

332

334

101E80" 98944650

Fig. 4

